① Desk top panel



1×

② Panel



1×

③ Bottom pulling bar 1



1×

④ Bottom pulling bar 2



1×

⑤ Bottom pulling bar 3



1×

⑥ Modesty panel



1×

⑦ Right side panel



1×

⑧ Left side panel



1×

⑨ Divider panel



1×

⑩ Solid wood leg



1×

⑪ Drawer front panel



2×

⑫ Drawer left side panel



2×

⑬ Drawer right side panel



2×

⑭ Drawer back panel



2×

A. Cam lock



48×

B. Cam cover



48×

C. Cam pin



48×

D. Dowel



16×

⑮ Drawer bottom panel



2×

⑯ Left rear solid wood leg



1×

⑰ Left front solid wood leg



1×

⑱ Right rear solid wood leg



1×

⑲ Right front solid wood leg



1×

⑳ Solid wood pulling bar 1



2×

㉑ Solid wood pulling bar 2



2×

㉒ Solid wood rail



1×

Model	PS601-1206
Name	End table
Size	1210W*600D*450H

E. Handle	F. Handle nails	G. Long pitch sell-tapping screw(black)	H. Fiber nail (color)	I. Telescopic screwdriver	M. Large f lat M8x35	N. Adjustable leveling glides
2×	 2×	 8×	 18×	 1×	1×	 1×



Step 1

Attention:First of all, put a piece of carton or rug on the floor,and then begin to install the panels, so as to prevent the parts from scratch.



Step 2



Step 3

Note: First tighten the solid wood pulling bar 1 and solid wood rail, and then screw.



Step 4



Step 5



Step 6



Step 7



Step 8

Note: The left part



Step 9

Note: The right part



Step 10



Step 11



Step 12

Note: There are two parts in this drawer, the installation diagram is as follows.



Step 13



Step 14

Note: After installing all the blocking latches, put on the cover sticker.



Step 15



Step 16